3. Function Select Toshiba HOME ESTIA application.

Status Indicator
Compressor / Electrical Back-up Heater /
Water Pumps / Boiler

Lights for operation mode for
which leaving water temperature
is to be changed.

Leaving water temperature setting

AUTO MODE On/Off
(for auto-curve operation: automatic
leaving water temperature setting
function of Air Outdoor temperatures,
for best energy savings)

Mode Select / On-Off

Special feature

Water temperatures before
back-up heater (TWO sensor)

Water temperature after
back-up heater

※1 depend on ESTIA Setting